

Jumper Settings

SCSI ID Switches

SW #	1	2	3	4	5	6	7	8	9	SCSI ID
	0	0	0	-	-	-	-	-	-	ID 0 (default when shipped)
	1	0	0	-	-	-	-	-	-	ID 1
	0	1	0	-	-	-	-	-	-	ID 2
	1	1	0	-	-	-	-	-	-	ID 3
	0	0	1	-	-	-	-	-	-	ID 4
	1	0	1	-	-	-	-	-	-	ID 5
	0	1	1	-	-	-	-	-	-	ID 6
	1	1	1	-	-	-	-	-	-	ID 7

SCSI1/2 Mode when ATA device is used

SW #	1	2	3	4	5	6	7	8	9	SCSI-1/2 Mode
	-	-	-	0	1	0	-	-	-	SCSI-2
	-	-	-	1	1	0	-	-	-	SCSI-1

ATA transfer mode when an ATA device is used

SW #	1	2	3	4	5	6	7	8	9	ATA transfer mode
	-	-	-	-	-	-	0	-	-	PIO transfer
	-	-	-	-	-	-	1	-	-	DMA transfer

ATAPI device type when an ATAPI device is used

SW #	1	2	3	4	5	6	7	8	9	ATAPI device type
	-	-	-	0	0	0	0	-	-	Normal (CD-ROM, etc.) *Default when shipped
	-	-	-	0	0	1	0	-	-	CD-Changer (LUN 0-5)
	-	-	-	0	0	0	1	-	-	PD
	-	-	-	0	0	1	1	-	-	LS-120

Flash ROM

SW #	1	2	3	4	5	6	7	8	9	Flash ROM
	-	-	-	-	-	-	-	0	-	Normal *Default when shipped
	-	-	-	-	-	-	-	1	-	Rewrite Mode

Termination

SW #	1	2	3	4	5	6	7	8	9	Internal SCSI Termination SW
	-	-	-	-	-	-	-	-	0	Termination ON *Default when shipped
	-	-	-	-	-	-	-	-	1	Termination OFF

*0 = jumper not inserted. 1 = jumper inserted.

*JPX is released/short-circuit to GND

REQ Buffer setup connector (CN5)

SW #	A	B	C	Internal SCSI Termination SW
	1	0	0	Open Drain
	0	1	1	3-state v *Default when shipped